



Slotting last bottom drawers first, then fixing the front drawers. Repeat the same on the rest of the drawer. You can only fix and complete one drawer at once.

